

115 Volt 3B & 3BX Consumables & Repair Parts

MOTORS/MOTION CONTROL	
Part #	Description
NOP-33280	Motor Mount Assembly (Includes board & motor)
NOP-33287	Motor Mount Cable
NOP-33286	Torsion Spring
NOP-33298	Bearing & Rail Combo 85mm (Left/right)
NOP-33168	Bearing & Rail Combo 55mm (Up/down)
NOP-33293	Holder (Post & chuck)
NOP-33284	Board Interface (Board only with two optical switches)

POWER BOARDS	
Part #	Description
NOP-55510	Power Cord
NOP-77428	Power Supply (24V)
NOP-33315	PCB (Mother Board) Assembly
NOP-33661	Display Assembly
NOP-33311	Display Cable
NOP-33312	Display Power Inverter
NOP-33318	Fan Assembly
NOP-33346	Keypad Assembly (3B only)
NOP-33356	Keypad Assembly (3BX only)
NOP-33323	Keypad Cable (both keypads)

LIGHTING	
Part #	Description
NOP-33260	Lamp
NOP-33211	Cable Assembly Light Dimmer (Cable and Potentiometer)
NOP-33258	Cable Assembly Light (two wire cable only)
NOP-33223	Potentiometer (10K)

STAGE	
Part #	Description
NOP-90353	Stage Assy Long A (Standard)
NOP-90354	Stage Assy PTT Blocking
NOP-33334	Bumpers for Stage (Need 3)
NOP-22100020	Screws (need 3) 6-32 by 3/8 socket set screw cup point
NOP-90666	Fresnel Lens – Case Throat Kit (3B only – not X)
NOP-33181	Fresnel Lens – 3BX only

ACCESSORIES	
Part #	Description
NOP-33337	Foot Bellows
NOP-33350	Dust Cover
NOP-87611-11	Manual 3BX
NOP-87314-11	Manual 3B
NOP-33353	Vario Calibration Plate Assembly
NOP-50060	Barcode Scanner